

Importance of stress information in Engineered Geothermal Systems: Which attributes of stress are the most important and a strategy for measuring them.

Keith Evans (ETH-Zürich/DHMA)

## Why measure stress anyway?

In principle, EGSs can be developed without explicit knowledge of the state of stress in the reservoir: e.g.

- First well drilled vertical and stimulated.
- Subsequent wells drilled to pass through the peripheral regions of the microseismic cloud.
- Sufficient pumping power mobilised to cope with any wellhead pressure required to deliver the design flow rate (stress-controlled).

However, in practice it will not be long before the discussion turns to the state of stress in the reservoir

## Why is stress important?

One of the more important discoveries of crustal mechanics in the past 15 years is the realisation that the Earth's crust is generally close to failure, even in tectonically quiet areas (i.e. high levels of shear stress are the rule rather than the exception).

- This is the underlying reason why shear failure and attendant seismicity commonly result from fluid injection (i.e. the rock is weakened by the elevated fluid pressure).
- Since shearing represents the partial relaxation of the shear stress, and is the primary permeability creation mechanism, it follows that the natural Earth stresses supply most of the energy consumed in the hydraulic stimulation operation.

### Rosemanowes, Cornwall


#### First stimulation of Phase 1 reservoir

#### **Downward migration of seismicity:**

During stimulation of the Phase 1 reservoir, microseismicity migrated *downwards* more than 1 km.

#### **Explanation:**

Pore pressure increase required to initiate failure decreases with increasing depth due to the stress gradients (i.e. stress state becomes more 'critical' with depth).




adapted from Whittle and McCartney (1989)


# What attributes of stress are the more important for reservoir creation?

- The *magnitude of the minimum principal stress* is the primary factor controlling stimulation pressure, and hence dictates the pumping power that must be mobilised.
- The *orientation of the minimum principal stress* is a primary factor in determining the geometry of the stimulation volume (i.e. the dimensions of the stimulated volume will tend to be smallest in a direction with 30° of normal to the minimum principal stress axis).

Rhine Graben: Normal-faulting stress regime



Cooper basin: Thrust-faulting stress regime





## What attributes of stress are the more important for reservoir creation?

Any qualitative understanding of what is happening in the reservoir requires at least partial knowledge of the stress state, and full-reservoir modelling requires a full description.

## Simplifying assumptions for characterising the state of stress in a reservoir?

- 1) One principal stress is vertical


  There can and usually are local deviations from verticality, but on
  the large scale (> 100 m) these tend to average out.
- 2) The magnitude of the vertical stress is equal to the integrated overburden
  - This follows from (1) and means that the vertical stress can be measured from integrated density logs.
- 3) Stress magnitudes are laterally uniform and increase linearly with depth within the reservoir.
  - First-order approximation that smoothes out the inevitable local variations that reflect *heterogeneity* of the stress field. Sudden step-increases in stress magnitude have been seen (e.g. Fenton Hill EGS) and so the assumptions should be treated with caution and established through measurement

### Stress attributes that remain to be measured

- 1. Magnitude of minimum principal horizontal stress, S<sub>hmin</sub>
- 2. Orientation of minimum principal horizontal stress, S<sub>hmin</sub>-orient
- 3. Magnitude of maximum principal horizontal stress,  $S_{Hmax}$

To completely define the profile of each of the above attributes will require a spotvalue at some depth and a gradient (i.e at least one other value at a different depth). Thus there are six unknowns.

Some attributes of stress are more easy to estimate than others. The easiest are the magnitude and orientation of  $S_{hmin}$ . Usually the most difficult is the magnitude of  $S_{Hmax}$ .



## Methods of stress estimation for EGS reservoirs - preliminary remarks

There are many different methods of measuring stresses in rock masses.

Few are direct measurements of stress. Most methods infer stress indirectly from observations of the consequences of stress. They are only as good as the robustness of the relation used to map the measurement(s) to the in-situ stress state.

Core-based methods invariably measure some property of the microcrack population and relate it to the stress existing at the core's location using some assumptions. Regardless of concerns as to the 'robustness' of these assumptions, the resulting estimates at best relate to stress at a very small scale and are thus impacted by stress heterogeneity.

Very few stress measurement operations can be performed in a commercial EGS hot reservoir setting. The wells are extremely expensive and operators are reluctant to risk damaging or losing the well.

## Strategy for site stress characterisation

Assume that an exploration borehole (say to depth < 2.5 km with  $T < 120^{\circ}$ ) has been drilled at the site.

Take full advantage of this hole to characterise stress:

Run density  $(\gamma - \gamma) \log: S_V$ 

Hydraulic stress tests on natural fractures using packers [HTPF]: powerful constraints on  $S_{hmin}$  -orient and  $S_{Hmax}$  if enough tests performed.

Hydrofracture stress tests using packers:  $S_{min}$ .

Borehole sonic televiewer log [BHTV]: imaging of breakouts and drilling-induced tension fractures [DITFs]:  $S_{hmin}$ -orient and  $S_{Hmax}$ .

## Strategy for site stress characterisation

In the main borehole within the deep hot reservoir, the type of tests that can be conducted are severely limited (not least because of the difficulties with packers at that depth). Performing any operation more complicated that running a wireline log may be ruled out by the project management.

Run density  $(\gamma - \gamma) \log: S_V$ 

Borehole sonic televiewer log [BHTV]: imaging of breakouts and drilling-induced tension fractures [DITFs]:  $S_{hmin}$ -orient and  $(S_{Hmax}-S_{hmin})$ 


The extraction of stress magnitude information from the breakouts and DITFs is greatly improved if  $S_{min}$  can be estimated independently:

- Minifrac tests of top 20 m of open-hole section after sanding back
- Minifrac tests on lower 10-20 m of open hole using alloy packer
- Pressure limiting behaviour during stimulation requires two stimulation cycles to distinguish jacking from shearing



### Wellbore failure - a rich source of information about stress

The wellbore stress concentration around a fluid-filled borehole



Large differences between  $S_{Hmax}$  and  $S_{hmin}$  produce large variations in the tangent stress,  $S_{\theta\theta}$ , at the borehole wall with extreme values that can produce failure.


Compressive failure (breakouts) occurs in the direction of  $S_{hmin}$  if  $S_{\theta\theta}$  > compressive strength of the rock.

Tensile failure (DITFs) occurs in the direction of  $S_{Hmax}$  if  $S_{\theta\theta}$  < tensile strength.




### Wellbore failure: Drilling-induced tension fractures

## Additional (tensile) component due to cooling of the hole by the drilling fluid




FMI log of a 15 m section of borehole in granite run just after drilling.

An axial tension fracture can be seen running up the centre and margins of the image indicating the orientation of  $S_{Hmax}$  is North-South.



#### Variation of tangential stress around wellbore wall




### $S_{hmin}$ -orientation: estimated from breakouts & DITFs

Breakouts and DITFs commonly occur in deep holes.

They constitute the best indicators of  $S_{Hmax}$ -orient because they are simply related to stress and can be averaged over long sections of borehole.


Both can be detected from a sonic televiewer (BHTV) or formation micro-resistivity imager (FMI) logs.



Brudy et al, 1997

**DITFs** in the KTB hole.

### Breakouts and DITFs also constrain $S_{Hmax}$ -magnitude




Given knowledge of the  $S_{hmin}$ -profile from hydraulic data, we can find the  $S_{Hmax}$  profile that reproduces the observed mode and distribution of failure.

- -Requires knowledge of compressive and tensile strengths of the rock, and also the maximum cooling of the borehole wall during drilling (Measurement-While-Drilling data is ideal!)
- -The constraint is much weaker if the magnitude of  $S_{hmin}$  is unknown.

In strongly-inclined holes, the DITFs become en-echelon, and their detailed geometry can be analysed to further constrain the magnitude of  $S_{Hmax}$ .

## $S_{hmin}$ estimation: Limiting injection pressure



During stimulation, step increases in flow rate often result in progressively smaller pressure increases until a *pressure limit* is reached. This limit can reflect:

- 1) the jacking pressure, in which case it is  $S_{min}$
- 2) the shearing pressure in which case it is  $< S_{min}$

Since the interpretation is not unique,  $S_{\min}$  estimates derived from pressure limiting behaviour should be treated with caution.

The two cases can be distinguished if flow rate is cycled up and down since well injectivity increases due to shearing are permanent, whereas those due to jacking are reversible (although jacking is always accompanied by some shearing.)

This may be the only  $S_{min}$  estimate available in deep, hot reservoirs.